


# Sub-port



- When you want to change the port size, because of Air pipe ine, Operating time)
- 3 size (PT1/4, PT3/8, PT1/2)



A	B	C	D
PT1/4	32	24	M5
PT3/8	45	40	M6
PT1/2	45	40	M6